



Email : sales@scilabexport.com

Phone: +91-7082934803

Product Name :

Vicat Needle Apparatus With Dashpot

Product Code :

SLE/CE/50



Website: <https://www.scilabexport.com>, **Email:** sales@scilabexport.com

1226/1-5, Bengali Mohalla, Science Market | 133001, Haryana



Email : sales@scilabexport.com

Phone: +91-7082934803

Description :

Vicat Needle Apparatus With Dashpot (Product Code: SLE/CE/50) is a frame-mounted penetration instrument used to determine the standard consistency and the initial and final setting times of cement paste in construction-materials laboratories. Its distinguishing feature is a dashpot that lowers the needles gently onto the paste, and it comes with an initial needle, final needle and consistency plunger. It is built by **Jain Scientific Equipments Pvt Ltd (ScienceLab)**, an OEM manufacturer, at its own factory in Ambala, India.

Specifications

Parameter	Detail
Frame	Metallic frame bearing a freely movable rod with a cap at the top
Dashpot	Provided for gentle lowering of the needles
Needle set	One each: initial setting needle, final setting needle, consistency plunger
Vicat mould	Brass, 40 mm high; 80 mm internal diameter at the base and 70 mm at the top
Base plates	Glass base plate; mild steel base plate 5 in × 5 in (approx. 127 × 127 mm)
Product code	SLE/CE/50
Manufacturer	Jain Scientific Equipments Pvt Ltd (ScienceLab) — OEM
Country of origin	India (made in Ambala, Haryana)

What Is the Vicat Needle Apparatus Used For?

Three linked cement tests use the same frame. The consistency plunger first finds the water content that gives paste of standard consistency; the initial setting needle is then lowered at intervals until the paste starts to resist penetration, and the final setting needle shows when the paste has hardened so that it barely marks the surface. These results set the water content for mortar and soundness specimens and tell site engineers how long cement stays workable.

The dashpot damps the fall so each needle meets the paste without impact, making readings more repeatable between students and operators. It is a core piece of lab equipment for technical institutes teaching building materials. Clean the needle after every penetration, keep the moving rod free-running, and position the mould so that each test point is clear of earlier marks and of the mould edge.

What to Specify When Ordering

- Number of apparatus sets required for your class or testing bench
- Spare needles: initial setting needle, final setting needle or consistency plunger
- Extra brass Vicat moulds, and whether glass or 5 in × 5 in mild steel base plates are preferred

OEM M

Website: <https://www.scilabexport.com>, **Email:** sales@scilabexport.com

Jain Scie

1226/1-5, Bengali Mohalla, Science Market | 133001, Haryana

e Vicat



Email : sales@scilabexport.com

Phone: +91-7082934803